

HOW TO USE THE SOLIGOR T4 UNIVERSAL AUTOMATIC SYSTEM

Operation of these lenses is extremely easy, simple and fast. To assure proper operation, follow these step by step instructions:

- 1) Open the mount retaining-bayonet, by turning the outer ring (1) in anti-clockwise direction as indicated by the arrow "O" (2)
- 2) Set the diaphragm control (3) opposite the reference mark (4) on the lens barrel.

Note: Lenses for Miranda, Nikon, Pentax, and Canon (yellow and red engraved mounts), operate over the range of black engraved diaphragm openings.

Lenses for Minolta (green engraved) operate over the green engraved diaphragm openings.

- 3) For lenses, coupling the exposure system, note the mark on the T-4 lensmount "set pin here".
- 4) Alignment pin (5), indicated by an arrow on the T-4 mount, fits into the alignment slot (6) indicated by an arrow on the lens base. To permit the T-4 mount to seat properly into the lensbase, turn the diaphragm control slightly to the left or right, holding the mount pressed down.
- 5) When the mount is in place, close the mount retaining ring by turning the ring (1) in clockwise direction, as indicated by arrow "L" (7).
- 6) To remove the T-4 lensmount from the lens, push the lever (8) and turn the mount retaining ring (1) in anti-clockwise direction (2) and lift the mount from the lensbase.

